

Instructions

Lense interchange:

First make sure, that you have the left lens for the left part of the frame and the right lens for the right part of the frame.

OUT:

Hold the frame at the bottom and gently apply pressure to the lens from the bottom-backside until it pops out.

Please polish the lenses with your YEYKEY microfiber bag

YEYKEY®

IN:

Slide the topside of the lens from the front into the frame. Then gently apply pressure to the bottom of the lens until it pops back in.

THE INLAYS ARE DESIGNED TO BE INSERTED FROM THE BACKSIDE OF THE FRAME.

